



Apple TV Remote



Fire TV Remote



Name	Function
Touch Surface	Navigation, Playback Control, Select. <ul style="list-style-type: none"> Tap the touch surface left edge to Rewinds 10 seconds. Tap the touch surface right edge to Fast Forward 10 seconds. Swipe from the top down to reveal the Info Panel. Swipe from the bottom up to reveal the trickplay controls.
MENU	Goes back one screen.
Home	Returns to the Home screen of Apple TV.
Voice Control	Launches the voice control for Search and Playback (Pause, Skip, Forward, Backward).
Volume Up/Down	Controls the volume of TV.
Play/Pause	Plays or pauses content.

Name	Function
Microphone	Used for voice commands.
Voice Button	Toggles voice command on and off.
Navigation	Navigates within the on-screen guide/menus:
Back	Goes back one screen.
Home	Goes to Home screen.
Menu	Displays the menu.
Rewind	Rewind: Rewinds video
Play/Pause	Play: Plays video or resumes a paused program
Fast Forward	Pause: Pauses video Fast Forward: Fast-forwards video.